























Ersatzteile für:

112116

Bike Runner large




Pos.		Pos.		Pos.	
1	 x1  x2  x1	7	 x2  x2  x2  x1	13	
2	 x2  x2	8	 x2  x2  x2  x1	14	
3	 x2	9	 x2  x2	15	
4	 x2	10		16	
5		11		17	
6		12		18	

Ersatzteile für:

112116

Bike Runner large



	47410								
	Version								
Pos.	2.0								
1	50502								
2	50538								
3	50504								
4	50505								
5	50549								
6	50580								
7	50506								
8	50507								
9	50531								
10	-								
11	50566								
12	-								
13	-								
14	-								
15	-								
16	-								
17	50574								
18	-								