

Ersatzteile für:

112121

VIKING Dreirad Maxi



Pos.		Pos.		Pos.	
1	x1 x2 x1	7	x2 x2 x2 x1	13	x4 x2 x2
2	x2 x2	8	x2 x2	14	x2 x2
3	x2	9	x2	15	
4	x2	10	x2	16	
5		11		17	
6		12		18	

Ersatzteile für:

112121

VIKING Dreirad Maxi



	469.00			
	Version			
Pos.	4.2			
1	50502			
2	50503			
3	50504			
4	50598			
5	50555			
6	50758			
7	50506			
8	50510			
9	50511			
10	50519			
11	50562			
12	50514			
13	50520			
14	50531			
15	-			
16	-			
17	50571			
18	50596			