


Ersatzteile für:

112121

VIKING Dreirad Maxi




Pos.		Pos.		Pos.	
1	x1 x2 x1	7	x2 x2 x1	13	x4 x2 x2
2	x2 x2	8	x2 x2	14	x2 x2
3	x2	9	x2	15	
4	x2	10	x2	16	
5		11		17	
6		12		18	

Ersatzteile für:

112121

VIKING Dreirad Maxi



	46900								
	Version								
Pos.	2.0	3.0							
1	50502	50502							
2	50503	50503							
3	50504	50504							
4	50505	50505							
5	50555	50555							
6	50581	50595							
7	50506	50506							
8	50510	50510							
9	50511	50511							
10	50519	50519							
11	50562	50562							
12	50514	50514							
13	50520	50520							
14	50531	50531							
15	-	-							
16	-	-							
17	50571	50571							
18	50582	50596							