














Ersatzteile für:  
**112138**  
**Viking Kangaroo**



Pos.		Pos.		Pos.	
1		7		13	
2		8		14	
3		9		15	
4		10		16	
5		11		17	
6		12		18	

Ersatzteile für:  
**112138**  
**Viking Kangaroo**



	496.00			
	Version			
Pos.	2.0	2.1		
1	50501	50501		
2	-	-		
3	50504	50504		
4	50505	50598		
5	-	-		
6	50580	50580		
7	50509	50509		
8	50510	50510		
9	-	-		
10	-	-		
11	50571	50571		
12	50660	50660		
13	50520	50520		
14	50531	50531		
15	-	-		
16	-	-		
17	50572	50572		
18	-	-		