



Ersatzteile für:
112151
Easy Rider



Pos.		Pos.		Pos.	
1	x1 x2 x1	7	x2 x2 x2 x1	13	x4 x2 x2
2	x2 x2	8	x2 x2	14	x2 x2
3	x2	9		15	
4	x2	10		16	
5	x1 x2 x2 x2 x2 x2 x2 x2	11	x1 x2 x2 x2 x1	17	x4 x2 x2
6	x1 x2 x2 x2	12	x1 x2 x2	18	

Ersatzteile für:
112151
Easy Rider



	479.00				
	Version				
Pos.	3.0	3.1			
1	50501	50501			
2	50503	50503			
3	50504	50504			
4	50598	50598			
5	50558	50558			
6	-	50557			
7	50506	50506			
8	50510	50510			
9	-	-			
10	-	-			
11	50562	50562			
12	50515	50515			
13	50520	50520			
14	50532	50532			
15	-	-			
16	-	-			
17	50571	50571			
18	-	-			