





















Ersatzteile für:

112156

VIKING Multi Anhänger universal




Pos.		Pos.		Pos.	
1	 x4  x2  x2	7		13	
2		8		14	
3		9		15	
4		10		16	
5	    	11	  	17	       
6		12		18	

Ersatzteile für:

112156

VIKING Multi Anhänger universal



47600									
Version									
Pos.	2.0								
1	50520								
2	-								
3	-								
4	-								
5	50527								
6	-								
7	-								
8	-								
9	-								
10	-								
11	50590								
12	-								
13	-								
14	-								
15	-								
16	-								
17	50570								
18	-								