

Ersatzteile für:  
 112162  
 Mini Krippendreirad



Pos.		Pos.		Pos.	
1	x2	7	x1  x1	13	x1  x2  x2
2	x1  x1	8	x2  x2	14	
3	x2	9	x4	15	
4	x2  x2  x1	10		16	
5		11		17	
6		12		18	

Ersatzteile für:

112162

Mini Krippendreirad



Pos.	41414		41420		
	Version		Version		
	1.2	2.0	1.2	2.0	
1	50015	50015	50001	50001	
2	50002	50068	50002	50068	
3	50003	50003	50003	50003	
4	50004	50004	50004	50004	
5	50130	50142	50120	50143	
6	50023	50023	50023	50023	
7	50105	50067	50105	50067	
8	50006	50006	50006	50006	
9	50008	50008	50008	50008	
10	-	-	-	-	
11	50031	50079	50021	50077	
12	-	50106	-	50106	
13	50007	50074	50007	50074	
14	-	-	-	-	
15	-	-	-	-	
16	-	-	-	-	
17	50032	50073	50022	50078	
18	-	-	-	-	