





















Ersatzteile für:

112167

Mini Rutschdreirad mit Lenker




Pos.		Pos.		Pos.	
1		7	 x1  x1	13	 x1  x2  x2
2	 x1  x1	8		14	
3	 x2	9	 x4	15	
4	 x2  x2  x1	10		16	
5		11		17	 
6	 	12		18	

Ersatzteile für:

112167

Mini Rutschdreirad mit Lenker



	418			
	Version			
	41814	41820		
Pos.	2.0	2.0		
1	-	-		
2	50068	50068		
3	50003	50003		
4	50004	50004		
5	50141	50141		
6	50023	50023		
7	50067	50067		
8	-	-		
9	50008	50008		
10	-	-		
11	50069	50064		
12	50106	50106		
13	50074	50074		
14	-	-		
15	-	-		
16	-	-		
17	50073	50078		
18	-	-		