














Ersatzteile für:
112169
Mini Sulky



Pos.		Pos.		Pos.	
1	 x2	7		13	 x1  x2  x2
2		8		14	
3		9	 x4	15	
4		10		16	
5	 	11		17	 
6	 	12		18	

Ersatzteile für:
112169
Mini Sulky



	44814		44820		
	Version		Version		
Pos.	1.0	2.0	1.0	2.0	
1	50001	50001	50001	50001	
2	-	-	-	-	
3	-	-	-	-	
4	-	-	-	-	
5	50018	50018	50018	50018	
6	50017	50017	50017	50017	
7	50105	50067	50105	50067	
8	-	-	-	-	
9	50008	50008	50008	50008	
10	-	-	-	-	
11	-	-	-	-	
12	-	-	-	-	
13	50007	50074	50007	50074	
14	-	-	-	-	
15	-	-	-	-	
16	-	-	-	-	
17	50032	50073	50022	50078	
18	-	-	-	-	