





















Ersatzteile für:

112170

Mini Krippendreirad mit Steg




Pos.		Pos.		Pos.	
1	 x2	7	 x1  x1	13	
2	 x1  x1	8	 x2  x2	14	
3	 x2	9	 x4	15	
4	 x2  x2  x1	10		16	
5		11		17	
6	  	12		18	

Ersatzteile für:

112170

Mini Krippendreirad mit Steg



	44214		44220		
	Version		Version		
Pos.	2.0		2.0		
1	50015		50001		
2	50068		50068		
3	50003		50003		
4	50004		50004		
5	50142		50143		
6	50023		50023		
7	50067		50067		
8	50006		50006		
9	50008		50008		
10	-		-		
11	50079		50077		
12	50106		50106		
13	-		-		
14	-		-		
15	-		-		
16	-		-		
17	50073		50078		
18	-		-		