




























Ersatzteile für:  
**112176**  
**Mini Easy Rider**



Pos.		Pos.		Pos.	
1	 x2	7	 x1  x1	13	 x1  x2  x2
2	 x1  x1	8	 x2  x2	14	
3	 x2	9	 x4	15	
4	 x2  x2  x1	10		16	
5	  	11		17	 
6	  	12		18	

Ersatzteile für:  
**112176**  
**Mini Easy Rider**



	409.20				
	Version				
Pos.	1.0				
1	50001				
2	50068				
3	50003				
4	50004				
5	50183				
6	50264				
7	50067				
8	50006				
9	50008				
10	-				
11	50077				
12	50107				
13	50074				
14	-				
15	-				
16	-				
17	50078				
18	-				