























Ersatzteile für:

112179

Mini Ben Hur mit Pedalen



Pos.		Pos.		Pos.	
1	 x2	7	 x1  x1	13	 x1  x2  x2
2	 x1  x1	8	 x2  x2	14	
3	 x2	9	 x2	15	
4	 x2  x2  x1	10		16	
5		11		17	
6	  	12		18	

Ersatzteile für:

112179

Mini Ben Hur mit Pedalen



41120					
Version					
Pos.	1.0				
1	50001				
2	50002				
3	50003				
4	50004				
5	50143				
6	50023				
7	50067				
8	50006				
9	50008				
10	-				
11	50079				
12	50106				
13	50007				
14	-				
15	-				
16	-				
17	50078				
18	-				