












Ersatzteile für:
112181
Mini Fun Racer



Pos.		Pos.		Pos.	
1	 x2	7		13	
2		8	 x2  x2	14	
3		9		15	
4		10		16	
5		11	 	17	
6	 	12		18	

Ersatzteile für:
112181
Mini Fun Racer



		407.20			
		Version			
Pos.	1.0				
1	50104				
2	-				
3	-				
4	-				
5	-				
6	50264				
7	-				
8	50006				
9	-				
10	-				
11	50103				
12	-				
13	-				
14	-				
15	-				
16	-				
17	50099				
18	50459				